

Division of Plumbing

Frequently Asked Questions

Q: What type of plumbing work can a maintenance man do or not do?

A: A maintenance man can only repair plumbing to keep plumbing in good working order. A maintenance man cannot replace or install any type of plumbing, which includes the following: water heaters, toilets, tubs, showers, sinks, faucets, drains, vents, dishwashers, disposals, grease traps, sewers and water services.